



XDS Pro Receiver: Network Configuration Data Sheet

X-DIGITAL SYSTEMS

Skyview's Network Operations Center (NOC) is available to affiliates at any time for installation and trouble shooting at 877-503-8910.

C-Band Satellite:

- SES World Skies, SES-11
 - Vertically polarized
 - C-Band Frequency, located at 105 degrees W.L.
- Downlink frequency: 4167.85 MHz
L-Band receive frequency: 982150 kHz
Symbol Rate: 4074100 sps

Notes:

1. Your XDS Pro receiver must be connected to a full time internet connection (cable included).
2. Please refer to the Quick Start Guide for installation instructions.

Affiliate Website: <http://myxdsreceiver.com>

- Use this site to download the Discovery Tool to access your receiver for the first time
- Set the password, time zone and other default settings
- Set up receiver program schedule, relay closures and other features

Relay Closure Information:

XDS receiver allows any relays to be programmed to any of the 16 available relays on each 37 pin relay port. All relays are floating dry contact closures, with no reference to ground.

<http://myxdsreceiver.com/aff/documentation/discovery.html>

Please see the enclosed Quick Start Guide Section 3.3 for Audio Pinouts and Section 3.4 for additional details regarding Relay Closures.

URL for Discovery Tool:

<http://myxdsreceiver.com/aff/documentation/discovery.html>

NOC Technical Assistance:
877-503-8910 /480-503-8727

